



## KUUMAALUS

- ◆ Aseta alus soovitud kohale. Jälgi, et aluse paigutus tagaks kerisele kasutusjuhendis sätestatud ohutuskaugused.
- ◆ Reguleeri jalgade kõrgus nii, et kuumaalus oleks horisontaalselt, kindlalt ning ei kõiguks. Võimalusel kasuta vesiloodi.
- ◆ Aseta keris aluse keskele, et kõik aluse servad jääksid kerisest võrdsele kaugusele.
- ◆ Kontrolli veelkord, et alusele asetatud kerise ohutuskaugused on tagatud.

## PROTECTIVE BEDDING

- ◆ Place the protective bedding where you wish. Make sure that the location of the protective bedding ensures the safety distances specified in the operating instructions of the heater.
- ◆ Adjust the height of the legs so that the protective bedding is horizontal, firm and would not sway. If possible, use a spirit level.
- ◆ Place the heater in the centre of the protective bedding so that all edges of the protective bedding are equidistant from the heater.
- ◆ Check again that the safety distances of the heater on the protective bedding are guaranteed.



#huumsauna



[www.huum.eu](http://www.huum.eu)